

EQUIPMENT TO EXTRACT AND CLEAN INJECTOR SEAT SIEMENS on 2.0 - 2.2 HDI engine and BOSCH on 2.0 - 2.2 JTD engine



P.N.: 311056014

Description of components:

- 1) Complete unit to extract injector;
- 2) M17x1 screw with CH.30 Bosch M16x1,5 nut;
- 3) Siemens injector M17x1 screw;
- 4) 25mm bushing, 1/2" joint for the removal of electrical unit;
- 5) 29mm bushing ,1/2" joint for the removal of electrical unit;
- 6) Long support tower;
- 7) Short support tower;
- 8) 10 mm tool to remove solenoid;
- 9) Air delivery needle;
- 10) Hand tool to clean Siemens injector seat